

PROBLEM	PROBABLE CAUSE	SOLUTION
<p>Linting</p>	<ol style="list-style-type: none"> 1. Cover is worn. 2. Stock has insufficient lint or pick resistance. 3. Base stock picks. 4. Ink too tacky. 	<ol style="list-style-type: none"> 1. Replace cover. 2. Change paper. Install a brush or vacuum-type paper cleaner, or precook on a spare unit. 3. If serious, reject paper; change to more lint or pick-resistant stock. 4. Add gel tack reducer, ¼ oz.-to-½ oz. per pound of ink.