

PROBLEM	PROBABLE CAUSE	SOLUTION
<b>Plugging</b>	<ol style="list-style-type: none"> <li>1. Dust from dull-finished or soft papers.</li> <li>2. Ink too tacky.</li> <li>3. Too much ink.</li> <li>4. Lack of colouring matter in ink.</li> </ol>	<ol style="list-style-type: none"> <li>1. Dust off each sheet of paper before using. Use better paper stock.</li> <li>2. Add thin varnish or non-pick compound.</li> <li>3. Adjust the ink fountain.</li> <li>4. Add transparent white ink to the ink in the fountain.</li> </ol>