

PRODUCT PROFILE

UNI PRO ECO-WASH 2012 SW

Economical water-miscible wash for rollers & blankets

UNI PRO ECO-WASH 2012 SW wash contains no water but has the chemical property of coupling with water to form a solvent/water emulsion. In a single wash-up, **UNI PRO ECO-WASH 2012 SW** wash removes the solvent-soluble contaminants on rollers and blankets, while the water emulsion removes the water-soluble glaze caused by gum, etch, lint and spray powders. By adding 25% to 50% water to a water-miscible wash, you reduce product cost, raise flash point, lessen the emission of solvent vapor into the pressroom, offer better protection to your hands, reduce product odor, and minimize V.O.C.'s.

ADVANTAGES

- Economical, may be diluted with water up to 50%
- Gives faster wash-ups without residues
- Removes glaze and piling quickly
- Deep cleans rollers and blankets

DIRECTIONS

BLANKETS:

Must be used on a wet wash-up rag. Add **UNI PRO ECO-WASH 2012 SW** full strength to rag or mix with up to 50% water in a wash-up bottle to remove both water-soluble and solvent-soluble glaze as well as blanket piling and lint at the same time.

ROLLERS:

Apply **UNI PRO ECO-WASH 2012 SW** full strength or mixed with up to 50% water to remove wet ink, gum glaze, paper fibers and lint. Use with **UNI O.D. DEGLAZER** as part of a press maintenance system.

SPECIFICATIONS

- Flash point: 43.3°C (110°F)

Safety data sheet available upon request
Code 194

UNIGRAPH
INTERNATIONAL

51 BEAUVAIS, DELSON (QUEBEC) CANADA J5B 1W5 | T 450-632-5871 | 800-996-9918 | F 800-366-8812
www.unigraphinternational.com | service@unigraphinternational.com



CANADIAN PRINTING INDUSTRIES ASSOCIATION
ASSOCIATION CANADIENNE DE L'IMPRIMERIE

